



Control Booth contains:
 Dimmers 1 & 2, NonDim. 169, 170
 Multiple Breakered Edison

Key:

- Source 4 14"
- Source 4 19"
- Source 4 26"
- Source 4 36"
- Source 4 50"
- Source 4 Zoom 25-50"
- Source 4 PAR WFL
- Source 4 PAR MFL
- Source 4 PAR NSP
- Source 4 PAR VNSP
- Arri 6" Studio Fresnel
- Double House Light
- Single House Light

Purposes:

- SP = Special
- TT = Times Talk
- CH = Church
- Pod = Podium

Other:

- Hanging Mic Input
- Speaker power
- Small Speaker
- Regular Speaker
- Large Speaker
- Ethernet Port
- Dimmer Raceway
- ETCNet Port
- Wireless Access Point

Legend:

- Unit Type
- Unit Number
- Channel

Notes:

- See paperwork for color and accessories
- Non-Dim "nd" circuits are controlled by the dimmer system and have one stage pin and two Edison outlets.
- "4P" circuits are constant hot 120v, run to a breaker panel, 20k each with 15-20 twist lock outlets. The Times Center owns 5 Edison adapters.
- All units on Pipe 4 are yoked 45 degrees US.
- All units not drawn on pipe or with sidearms are yoked in that direction.
- All Box Boom units drawn without sidearms do not have them.

REVISION	DATE
U	8/28/14
C	8/2/11
Q	7/29/10
A	6/24/09
P	8/22/08
R	2/23/08
REVISIONS not info 11/10/07	
FIRST PROOF 10/24/07	

Jenn Desimone,
 Production Manager
 jennifer.desimone@nytimes.com
 Phone: 646-428-6429
 Fax: 646-428-6395

Tim Kaufman,
 Lighting Supervisor
 tim.kaufman@nytimes.com
 i.am.tim.kaufman@gmail.com
 Phone: 319-321-5272

Loading Dock:
 40th Street between 7th & 8th Ave

The Times Center
 242 W. 41st Street
 New York, NY 10018
 www.thetimescenter.com

LIGHT PLOT & GROUNDPLAN

Scale: 1" = 1'
 36"x48" paper = 1/2" = 1'
 18"x24" paper = 1/4" = 1'
 always check.

Plate: **1** of 2